


Brief instruction multimedia interface

Article-ID 35538 (Basic Plus), 35537 (Basic)

Detailed manual: <http://www.kufatec.de/infocenter/download/>


PIN Configuration

RNS-E, MFD2, RNS 510




Can High - PIN 9
Can Low - PIN 10
Ground - PIN 12
Red - Steady plus

RNS-D, MFD



Can High - PIN 13
Can Low - PIN 26
Ground - PIN 8
Red - Steady plus

Comand




Ground - PIN 8
Red - PIN 7

For **MFD2** the AV and AUX source have to be deactivated **before connecting**.

For **RNS 510** with **softwareindex 522 and higher** the CAN-Gateway (Address 19) has to be coded to TV. Please contact your VW-dealer!

PIN Configuration for factory fitted RVC



In case of factory fitted RVC the loom (35951) has to be connected to the 54-pole connector of the control unit for RVC.

The control unit can be located on different places within the vehicle.

Vehicle	Location RVC - Control unit
Touareg, Tiguan	Behind the cover in the trunk (ride hand side)
Passat 3C Variant	Behind the cover in the trunk (ride hand side)
Audi R8	Behind the cover driver seat

Wiring	Vehicle wiring
Red (Audio)	PIN 5 (if taken remove PIN)
Black (Audio)	PIN 4 (if taken remove PIN)
White (Audio)	PIN 7 (if taken remove PIN)
Blue	PIN 11
Gray	PIN 13
Yellow	PIN 15

Wiring	Vehicle wiring
Violett	PIN 17
White	PIN 18
Black/White	PIN 40
Black/Yellow	PIN 39
Brown (Ground)	PIN 44
Red	PIN 43

Fitting after market camera

The RVC has to process **NTCS** signals!

